






de Drucktransmitter  
fr Transmetteur de pression  
en Pressure transmitter  
it Trasmettitore di pressione  
es Transmisor de presión  
sv Trycktransmitter  
nl Druktransmitter

de Montagevorschrift  
fr Instruction de montage  
en Fitting instructions  
it Istruzioni di montaggio  
es Instrucciones de montaje  
sv Monteringsanvisningar  
nl Montagevoorschrift


de Installationsanweisung für die Elektrofachkraft  
fr Notice d'installation pour l'électricien  
en Guidelines for the electrician  
it Informazioni per l'installatore elettrico  
es Instrucciones de instalación para el electricista  
sv Installationsinstruktion för behörig elektriker  
nl Instalatie aanwijzing voor de elektromonteur




1a




1b




2




### 3.1









### 3.2



### 5



### 4



de Dokument aufbewahren  
fr Ce document est à conserver  
en Retain this document  
it Conservare il documento  
es Guardar el documento  
sv Spara dokumentationen  
nl Document bewaren

© SAUTER Head Office  
Fr. Sauter AG  
Im Surinam 55  
CH-4058 Basel  
Tel. +41 61 - 695 55 55  
Fax +41 61 - 695 55 10  
www.sauter-controls.com  
info@sauter-controls.com

UK Importer:  
Sauter (GB)  
Inova House  
RG24 8GG